



POE | PAG ID

Test to identify the Type of AC/R Lubricant (either POE or PAG)

POE | PAG ID is a test that recognizes several synthetic Lubricants.

It is an easy and sensitive method to distinguish POE and PAG Oils.

The test releases a LIMPID solution in case of PAG and TURBID one if it's a POE Oil.

The test is not distorted by the color of the Lubricant or the presence of foreign elements. On the contrary, it is a quick and precise proposal that eliminates any doubt about the kind of Lubricant in use in the plant.

It takes just a few moments for the result: just pull out of the System some Lubricant, according to each single procedure.

Insert 3 mL of sample Lubricant into a flask, shake vigorously and observe the result. As indicated, if it is PAG, the solution will remain clear. In the presence of POE lubricant, the solution will become turbid.

Each flask is disposable. Do not reuse the solution after a test, even if it is still clear: the presence of PAG Lubricant would fail the result.

For professional use only: wear protective gloves.

